

---

Subject: amp enclosure

Posted by [blake](#) on Mon, 26 Mar 2007 06:08:30 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm building an enclosure for an amp I just built and I have a question about recessing the top plate. I used a rabbet bit to cut out a shelf for the top plate to sit on. The problem is that at the corners I have to pull the bit off the wood and it leaves a curve rather than a square end. Should I just chisel out the last little bit of wood or is there another, better looking way of doing it? Thanks for any suggestions. Blake

---

Subject: Re: amp enclosure

Posted by [Bill Epstein](#) on Mon, 26 Mar 2007 14:06:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

As you've discovered, if you cut the rabbet after gluing up the box you're left with the rounded corners. Just use 1/2" or bigger chisel to cut the square. Use the extra width of the flat edge to index against the already cut side of the rabbet. Alternate your cuts from one side of the corner to the other so as not to have a split.