

---

Subject: Theater Seven Pi--so far so good!

Posted by [AudioLapDance](#) on Mon, 18 Jun 2001 15:22:35 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne, Replay and y'all!! I finally started into my Theater 7 Pi s! I just built the box part of the corner horn (the rest is just a positioning device) and they are still monsters! I used 3/4 MDF and put #8, 1 1/2" particle board screws every 2 inches!!! Over kill I know, but they look like they have rivets around the outside-sort of an industrial / Mad Max look. I like it! I might even leave them unfinished! Do I use 2" fiberglass insulation (pink, itchy stuff) on the walls adjacent to the port (all I can find so far are 3/4" insulated drop-ceiling tiles and 3.5" house insulation)? What type of screws do you prefer to mount the drivers? Thanks, Jeff

---

Subject: Re: Theater Seven Pi--so far so good!

Posted by [Wayne Parham](#) on Tue, 19 Jun 2001 06:18:16 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Good work, Jeff!! use R13 insulation for acoustic damping material and 1/4-20 screws and T-Nuts to mount the drivers. Keep us posted on your progress!