

it is Advisable to use a L pad for the 4 Pi?

Subject: Lpad's provide incorrect damping for the network Posted by Wayne Parham on Sun, 18 Nov 2001 20:12:19 GMT View Forum Message <> Reply to Message

Don't use a standard 8 ohm L-Pad because damping is wrong for the compensation network. Use the suggested R1 and R2 components instead.