

---

Subject: Compressed fiber carpet pad for cabinet damping?

Posted by [Garland](#) on Sun, 16 Dec 2001 00:04:02 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I have a bunch of this wool-like 1/2" thick carpet pad that I got for use in a tapered quarter wave tube project and was wondering if it can adequately be used to line the specified interior surfaces of my Theater 4's? It is pretty dense stuff- not fluffy like insulation that I've heard is OK to use. Can anybody help me out here? What is best to use? Thanks!Garland

---

Subject: Use 2" fiber-filler

Posted by [Wayne Parham](#) on Sun, 16 Dec 2001 01:21:10 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm afraid that stuff will be too thin and dense. Use 2-3" thick fiberfill like is in the attic of your home. R11 or R13 is perfect.