Subject: Enter PiAlign numbers in BoxPlot?
Posted by craigha@attbi.com on Tue, 01 Jan 2002 14:29:36 GMT
View Forum Message <> Reply to Message

I'm trying out PiAlign and BoxPlot for thefirst time. Some questions.PiAlign recommends a 16.7x11.1x7.4 inch cabinetvent 2.2" dia. 2.3" len.Enclosure Fr 55Enclosure Q 1.5I'm confused on how to simulate this in BoxPlot.The port and cabinet dimensions are auto. setwhen BoxPlot aligns.What is the procedure to enter the PiAlign numbersand model with them?Thanks.P.S. I have some RadioShack 40-1354A drivers and wouldlike to try them in a PiAlign box with a Motorola KSN1038.