

---

Subject: Enter PiAlign numbers in BoxPlot?

Posted by [craigha@attbi.com](mailto:craigha@attbi.com) on Tue, 01 Jan 2002 14:29:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I'm trying out PiAlign and BoxPlot for the first time. Some questions. PiAlign recommends a 16.7x11.1x7.4 inch cabinet vent 2.2" dia. 2.3" len. Enclosure Fr 55 Enclosure Q 1.5 I'm confused on how to simulate this in BoxPlot. The port and cabinet dimensions are auto. set when BoxPlot aligns. What is the procedure to enter the PiAlign numbers and model with them? Thanks. P.S. I have some RadioShack 40-1354A drivers and would like to try them in a PiAlign box with a Motorola KSN1038.