
Subject: question about fasteners and dampening
Posted by [ray99](#) on Wed, 29 May 2002 11:18:23 GMT
[View Forum Message](#) <> [Reply to Message](#)

Hello. Just received my thermionic 3 kit yesterday. Does anyone know the specs for the three types of fasteners: 1) to attach horn to eminence psd2002-82) to attach horn assembly to front baffle (seems like it has a lot of leverage against the baffle) 3) to attach woofer to front baffle (hoping I can buy parts at home depot) also do you use a dampening material in the cabinet? the directions don't mention dampening except to say that crossover should be on fiberglass blanket; should the interior walls of cabinet be lined with a dampening material? thanks for helping a newbie. Ray

Subject: Re: question about fasteners and dampening
Posted by [BillEpstein](#) on Wed, 29 May 2002 13:29:45 GMT
[View Forum Message](#) <> [Reply to Message](#)

1. My PSD is the screw on type, I'll defer 2. 10-32 t-nuts and cap head screws for the horn 3. 1/4"-20 t-nuts and cap head screws for the woofer BTW, all this, including numerous sources for the hardware are easily found in the archives. Pretty soon, you'll be citing archive posts to other newcomers. Welcome!

Subject: Re: answers about fasteners and dampening
Posted by [Wayne Parham](#) on Wed, 29 May 2002 20:32:53 GMT
[View Forum Message](#) <> [Reply to Message](#)

To mount the compression driver to the horn, use two 1/4"-20 bolts; You should find them in the the baffle, T-nuts and screws are excellent. I prefer them for larger speakers. For smaller ones, I like to use #8 pan screws

Subject: thanks Wayne and Till E. (nt)

Posted by [ray99](#) on Thu, 30 May 2002 10:11:04 GMT

[View Forum Message](#) <> [Reply to Message](#)

.