Subject: Theater 7 pi corner horn plans please Posted by berlin on Thu, 28 Aug 2003 20:47:15 GMT View Forum Message <> Reply to Message

Wayne, I've just been checking out the speakers and they look great. I think the Theater 7 pi corner horn has real potential and I'm interested in seeing what it will take to construct. On your web site you list the complete price and the kit price. Can you please let me know what the difference is between the two? Thanks, berlin

Subject: You've got mail! Posted by Wayne Parham on Thu, 28 Aug 2003 21:13:15 GMT View Forum Message <> Reply to Message

I've sent the plans to you, but I'm not sure if Yahoo accounts will accept files with attachements this large. If you don't receive mail or I get an error saying your mailbox is full, we'll make other arrangements to get plans to you.Completed speakers are just that - Fully assembled loudspeakers that are ready to play. Kits include the speaker drivers, the connector panel, hook

compression tweeter and crossover network, kits also include the crossover, tweeter compensation cable assembly, Zobel woofer damper, and all cable assemblies are completed and ready to install. Every kit containing a compression driver also includes the horn flare and the bolts to mount the driver to the horn. So basically, a kit is everything you need except the cabinet, and the idea is that you will build them yourself or have a local cabinetmaker build them for you. Then you just install the components and you're ready to go.

Subject: Re: You've got mail! Posted by berlin on Thu, 28 Aug 2003 21:54:56 GMT View Forum Message <> Reply to Message

Wayne, Thanks very much - I received them fine! I'll look them over. One question I have is how large does the corner of the room have to be for the speakers? Right now I have a full wall on one side and about 8" on the other side. Thanks, berlin

## Subject: Corners or not

a minimum, and six feet would be better. These speakers are pretty forgiving of some corner shape imperfections, but you don't want the wall to be interrupted immediately by an entryway or

Subject: Re: Corners or not Posted by berlin on Fri, 29 Aug 2003 08:29:06 GMT View Forum Message <> Reply to Message

a sensitivity of 100dB minimum - the more the better. The reason for this is that I want to build some truly flea-powered tube amps and 3/4 watt and 1 watt need all the help they can get.Can

Subject: Plans sent Posted by Wayne Parham on Fri, 29 Aug 2003 08:34:20 GMT View Forum Message <> Reply to Message

Page 2 of 2 ---- Generated from AudioRoundTable.com