

---

Subject: Plans For Stage Series 6 Pi  
Posted by [mgzny](#) on Thu, 09 Oct 2003 16:21:15 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi Wayne: Thanks for all the help with the 414Z and of course for your patience. Like to give these cabinets a try. How much free wallspace do I need? Regards, Mark

---

---

Subject: You've got mail!  
Posted by [Wayne Parham](#) on Thu, 09 Oct 2003 20:46:02 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

For cornerhorns, you'll want about three feet of unobstructed wall space. Since you're planning to use the Altec 414's, please use the cabinet dimensions I sent to you via. E-Mail. I'll send plans for

as described in my letter. PiAlign recommends 1.6 cubic feet tuned to 56Hz for the Altec 414. This is a fairly small cabinet, but response looks great with -3dB point at 60Hz and -10dB at 45Hz. Cabinet dimensions should be 29 x 16 x 8.5 with a rectangular port having HxW dimensions of 2.875" x 5.125" and 4.0" long.

---