
Subject: Impedance at resonance and tube amps
Posted by [Duke](#) on Sun, 12 Oct 2003 15:43:51 GMT

[View Forum Message](#) <> [Reply to Message](#)

Wayne -If I understand correctly, the Theater 4 Pi works great with SET's and such; the Theater 3 Pi does not work well with tube amps (especially not SET's); and the Stage 4 Pi works pretty well with tube amps down to about 10 watts. Not having read every post you've made on the subject, from what I have read I gather that the issue at hand is the woofer's impedance at resonance. The Delta 15 in the Theater 4 Pi has a Zmax of 52 ohms; Delta 12LF in the Theater 3 Pi has a Zmax of 93 ohms; and the Omega Pro 15 in the Stage 4 Pi has a Zmax of 122 ohms. I would have thought that a fairly low Zmax would be desirable for a tube amp, but evidently the high Zmax Omega 15 works better than the medium Zmax Delta 12 LF. I'm probably taking bits and pieces out of context - could you show me the big picture, or point me to a source? Thanks! Duke

Subject: Re: Impedance at resonance and tube amps
Posted by [Wayne Parham](#) on Mon, 13 Oct 2003 03:10:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

I've found some SET amps that don't seem particularly sensitive to load and others that are very sensitive. The issue is that as source impedance is increased, the resulting circuit acts more like one having constant current. This makes the woofer excursion vary purely because of the electronics, which sets the amount of motor drive and damping. What you have essentially is a voltage divider, where both impedances are fairly significant, and one of them varies considerably at different frequencies. If the amplifier has very low source impedance, then it acts like a constant voltage source. It acts like there is no voltage divider, because the source is essentially "shorted." When full power is applied, the voltage across the motor goes to the rails. And when no voltage is applied, it acts like the motor is shorted. So the load impedance doesn't interact with the source impedance very much as a voltage divider. These effects are quite noticeable when you take a motor with high Zmax and compare its behaviour in a circuit having strong drive/damping ability to another having high source impedance. You can drive a speaker having low Zmax with either of two amps having different damping factors and you might not hear much difference if the amps are comparable in other respects. But put a speaker with high Zmax on the amps, and you'll definitely notice it. Try this experiment: Take a high-power solid-state amp and drive a speaker with low Zmax. Now take the same amp and put a series resistor inline, of say 10 ohms. The low Zmax speaker won't peak too much, and you won't notice the difference in frequency response. You might hear the reduction in output, but the response curve will be fairly similar so the speaker will sound similar. But do the same thing with a high Zmax speaker. You'll hear the difference now. There are some SET amps that have high enough source impedance that they act this way. So they probably are best paired with speakers having low Zmax.

Subject: Re: Impedance at resonance and tube amps

Posted by [Duke](#) on Tue, 14 Oct 2003 11:54:14 GMT

[View Forum Message](#) <> [Reply to Message](#)

Thank you, Wayne! I am constantly amazed at the wealth of knowledge you so freely share. Best regards,Duke
