

---

Subject: more stupid questions

Posted by [r. wood](#) on Wed, 12 Nov 2003 20:28:41 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

I put insulation on the baffel board. Is that ok?. just found the directions and they didnt say anything about insulation there . but i think ive got everthing else right. knock on WOOD.

---

Subject: Insulation

Posted by [Wayne Parham](#) on Thu, 13 Nov 2003 03:27:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Like Bill said, the best bet for R13 is "live-end, dead-end" and if there's too much inside, you'll de-tune the system.

---

Subject: "live-end, dead-end"?

Posted by [GarMan](#) on Thu, 13 Nov 2003 11:10:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

What does "live-end, dead-end" mean?

---

Subject: Re: "live-end, dead-end"

Posted by [Wayne Parham](#) on Thu, 13 Nov 2003 14:30:09 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

One side is treated with absorbent material, the opposing wall is left untreated and reflective. This term is used a lot to describe room treatments, or rather a specific listening room condition.