
Subject: silly seven cornerhorn question

Posted by [artsybrute](#) on Wed, 21 Jan 2004 15:42:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

Hi again.I've got all the wood cut up (except for the doghouse angles) and am running out to Home Depot for the insulation.I understand it should be 2" stuff without backing, which I think is R-13.How does the insulation get attached? The only reference I can find is in the attached link which specifies PL400 Deck Adhesive. What is that, and if I cannot find it what is the generic name for something I could use?Thanks,Len

One for the Fridge post

Subject: Re: silly seven cornerhorn question

Posted by [Matts](#) on Wed, 21 Jan 2004 16:17:07 GMT

[View Forum Message](#) <> [Reply to Message](#)

Lots of ways to attach it- I think the easiest is to use a spray adhesive that comes in an aerosol can. Of course, now that I'm typing this, I can't remember the brand I've used, but they sell it at Home Depot. I think it's made by Dupont. It's used for mounting photos, displays, almost anything and very easy to use, and much stickier than you'd imagine.I got R-13 with backing and tore the paper off cause for some reason it was much cheaper than the kind without backing. Don't forget some cheap work gloves you can use and throw away.

Subject: Attaching R-13 insulation

Posted by [Wayne Parham](#) on Wed, 21 Jan 2004 16:22:59 GMT

[View Forum Message](#) <> [Reply to Message](#)

You're right about using R-13. Peel off the water barrier paper and attach it with white glue or with a staple gun. A powerful staple gun will drive the staples in firmly, and does a pretty good job. But if they come unlodged, you'll have them bouncing around inside. Using white glue eliminates that possibility, but it takes longer to do.

Subject: Thanks Matt! (nt)

Posted by [artsybrute](#) on Wed, 21 Jan 2004 16:23:26 GMT

[View Forum Message](#) <> [Reply to Message](#)

Subject: Spray adhesive
Posted by [Wayne Parham](#) on Wed, 21 Jan 2004 16:23:57 GMT
[View Forum Message](#) <> [Reply to Message](#)

Great idea. There you go!

Subject: Thanks Wayne
Posted by [artsybrute](#) on Wed, 21 Jan 2004 16:37:01 GMT
[View Forum Message](#) <> [Reply to Message](#)

I'll mask the non-damped sides (really only one short side before closing the box up by adding the driver plate and top) and spray like matts said. Regards, Len

Subject: Re: silly seven cornerhorn question
Posted by [Duncan McBride](#) on Wed, 21 Jan 2004 18:04:27 GMT
[View Forum Message](#) <> [Reply to Message](#)

It's 3M Type 77 spray adhesive. Office Depot should have it too. I use it like contact cement - a good coat on each surface, let it dry until real tacky (but not gooey wet), and stick together. I used a staple in the corners too. An old belt and suspenders man.

Subject: Re: Yeah, that's the stuff.
Posted by [Matts](#) on Wed, 21 Jan 2004 19:03:42 GMT
[View Forum Message](#) <> [Reply to Message](#)

I remembered it had a number in the name... I didn't find any need for belt and suspenders with this stuff, but never hurts. I sprayed it on the interior, thought nothing was happening, touched it and my finger stuck! I just used a coat on the wood, pressed the insulation on and it's been fine. One of those better living through chemistry things...
