Subject: Looking for veneer tips for my Pis Posted by James W. Johnson on Tue, 13 Jul 2004 13:53:04 GMT

View Forum Message <> Reply to Message

Anways I am ready to finish my Pi speakers , the boxes are prepped and ready to get veneered. This time I ordered a few sheets of 10 Mil paperbacked veneer from Tape Ease in hopes I will be successful this time. I have read of a few of you guys that use glue and an iron but i'd rather use contact cement. Anyhow these are fairly big at ~ 30" x 14" x 18" so thereis plenty of room for error. :-)1. will I have issues with the veneer sticking to the PCV ports? They are perfectly flush with the baffle. 2. Tape-Ease says that trimming is best done with a utility knife ...last time I did trim this way and the wood splintered. / How long after applying should you trim? I always trim my laminate right away. Thats all for now...I expect to start veneering next weekend so I have several days to consider it and come up with a plan. I'd appreciate some tips or tricks on how to best tackle this job. The cabinets have been sanded down to 120 grit and were washed with water and a rag afterwards.

Subject: Re: Looking for veneer tips for my Pis Posted by GM on Tue, 13 Jul 2004 15:19:40 GMT

View Forum Message <> Reply to Message

I have a whole book devoted to this subject, but out of curiosity I did a 'veneering tips' Google search and lo n' behold, the first link was Tape Ease, so considering this is the brand you bought, it seems reasonable to me to just follow their instructions WRT to prepping for the material you used, etc.. GM

Subject: Re: Looking for veneer tips for my Pis Posted by Wayne Parham on Tue, 13 Jul 2004 22:20:27 GMT

View Forum Message <> Reply to Message

Run this by the guys on the Craftsmen forum too. A lot of them check this forum from time to time, but just in case, I'd make a post there.