

---

Subject: 7pi

Posted by [j.luis cruz](#) . on Mon, 30 Jan 2006 00:05:08 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hy again Wayne..in the 7pi crossover diagram regarding to L2 you say that the value is driver dependent with delta 10 a value but with alpha 10 the value is 0.0 Mh . that must understand by value 0.0 no inductor when using the alpha in the 7pi .thanks

---

---

Subject: Re: 7pi

Posted by [Wayne Parham](#) on Mon, 30 Jan 2006 15:10:40 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

That's right. Drivers that use a "0mH" coil don't use a coil. It's a straight wire connection.

---