

---

Subject: Re: Help with '45' problem?

Posted by [akhilesh](#) on Thu, 18 Aug 2005 19:25:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Some thngs to check:1. Are you using the same RCA jack for all inputs?2. Have you tried a couple of different CD players?3. Have you switched interconnects and tried it?thanks-akhilesh

---