

---

Subject: Turntable setup question

Posted by [Cam Ewart](#) on Sun, 25 Jan 2004 02:40:13 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello all,I am wondering if someone could offer some advice. Every turntable I have ever owned has the same problem. The last 2" or so on each side starts to sound distorted, with loss of treble and poor sound quality in general.Naturally I check to make sure the needle isn't dirty, then I put it back down and the same thing happens. If I then jump back to the start of the album, everything sounds great...I had my Technics SL1200MkII 'professionally' set up by the local store - should this be happening?Thanks for any info,Cameron Ewart

---