

---

Subject: Help!

Posted by [Sarah](#) on Tue, 13 Apr 2004 19:40:34 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi,I was wondering if anybody could answer a quick question. My mum recently bought me a second-hand record player (Akai AP-D33). When I went to play something on it, it soon became apparent that the speed was wrong. LPs sound fine if they're played at 45rpm, whereas 33 1/3 rpm is way too slow. So I can't play 7" at all. Is this a fixable problem or will I have to buy another turntable?Thanks in advance,Sarah

---