

---

Subject: Re: 7" slower than 12"?

Posted by [Christian](#) on Fri, 30 Jul 2004 17:36:12 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi, many thanks for your reply. I'm trying to do the best that I can with my english!. My 7" singles play all at 45 RPM. Maybe the turntable needs some oil for lubrication because it was a long time without use or maybe there is something wrong with the internal mechanism. But anyway I think it is strange because my LPs play fine... well, in fact the LPs goes a little slower than the CD versions, but it is almost imperceptible and the only way to realise that is playing both turntable and the CD simultaneously. Actually I don't know if it is the way that it supposed to be or there is something wrong.(By the way, the turntable is a Pioneer PL-7, from 1982 I think)... Any suggestion? Thanks again.

---