

---

Subject: Re: Bad connection in arm of Dual 601 Turntable  
Posted by [Wayne Parham](#) on Fri, 19 Nov 2004 06:50:26 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

Hi Harry, Sounds to me like you've identified the problem, so 1/2 of the deal is done. At least you know the cause is a bad connection. Now the matter is what to do to solve it. Where is the connection that you've cleaned? What's to stop you from simply re-wiring? I think I'd be most comfortable with that solution. Just in case the problem was caused by an open inside a wire, probably as it enters a crimp connection. You could be moving that when you clean it, making it work for a little while. If you can re-wire, that will replace both the connector and the wire. Wayne

---