Subject: AR turntable

Posted by David Teves on Fri, 18 Feb 2005 01:17:33 GMT

View Forum Message <> Reply to Message

I have an AR turntable that develops a hum that begins when the tone arm is placed above the outer edge of the record. It is not very loud, but it is very annoying. Does anyone have a guess as to whether this is being caused by the tone arm or the cartridge? Or anything else? Thanks!