
Subject: correct dc voltage for the Thorens 147 turntable
Posted by [pinloong](#) on Mon, 18 Apr 2005 05:07:38 GMT
[View Forum Message](#) <> [Reply to Message](#)

Bought a Thorens 147 turntable which came with a non-original adaptor for 9volts dc. Am in fear of damaging the motor should this voltage be too high and would appreciate very much information on the right dc voltage for this Thorens model. Thanking you in advance as I could then put this turntable into service without worry.
