

---

Subject: Re: correct dc voltage for the Thorens 147 turntable

Posted by [pinloong](#) on Tue, 19 Apr 2005 05:42:01 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thank you, manualblock. Just saw the piece of paper pasted on the tt chassis when the platter was removed. It says something like 15v or more but it also has a wave sign(ac?). Just wondering what that means but I am getting a 16volter as you indicated. Or one as close as possible if I can't?

---