

---

Subject: Re: SONY PS LX250H voltage  
Posted by [Wayne Parham](#) on Sat, 21 May 2005 13:09:04 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

You can use a transformer but it costs more than your turntable does. You're probably better off getting another turntable.

---