

---

Subject: Turntable refuses to rotate

Posted by [line](#) on Wed, 25 May 2005 12:15:44 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hello, I found this forum in a web search, and I hope someone here can help. I have an auto-return turntable phonograph (Sanyo TP B2) that looks something similar to the ones in this picture: <http://en.wikipedia.org/wiki/Image:TurntablesWWOZ.jpg> Today I rotated the turntable clockwise manually while I was cleaning its surface with a towel. Apparently I messed up something, because since then, the turntable doesn't work. I put a platter on, mount the arm (which turns on the phonograph), but the turntable doesn't rotate. It's not stuck, though, I can still turn it manually. Is this a common problem? What can I do about it? Thanks!

---