

---

Subject: Re: Turntable refuses to rotate

Posted by [Wayne Parham](#) on Wed, 25 May 2005 14:04:43 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The turntable you mentioned has a belt drive. If you rotate the platter by hand, you may have dropped, stretched or broken the belt. Remove the record mat and look and see if the belt is off.

---