Subject: Re: Turntable refuses to rotate
Posted by Wayne Parham on Wed, 25 May 2005 14:04:43 GMT
View Forum Message <> Reply to Message

The turntable you mentioned has a belt drive.  If you rotate the platter by hand, you may have dropped, stretched or broken the belt.  Remove the record mat and look and see if the belt is off.