Posted by Mr Vinyl on Mon, 11 Jul 2005 13:52:00 GMT

View Forum Message <> Reply to Message

Hi,Sounds to me like the VTF is not set correctly (that is too light). Purchase a VTF gauge and make sure your setting is correct. Shure makes a cheap one that can be had over the internet from places like Music Direct. If you VTF is correct and this still happens it must be the anti-skate setting is way too high. I would start with my first suggestion.