Subject: Um.. I am the Village Idot but it won't turn on...
Posted by Amanda on Sat, 10 Sep 2005 07:11:49 GMT
View Forum Message <> Reply to Message

OK i feel dumb. I've recently 'inherited' an '70 Bsr Professional 2260 AG from my folks. I can't get the thing to turn on. It seems like the slide selector, the thing that you move to turn the player to 'off', 'on , or 'auto' is stuck. It simply will not move. It is pluged in to a power source . That was the first thing my Dad asked when i saught his advice. His response to my dilema is that he hasn't looked as the thing in 20 years so i'm on my own. Is there a trick to this thing? Any suggestions?