
Subject: denon dp-47f

Posted by [jaudio](#) on Sat, 15 Oct 2005 18:57:27 GMT

[View Forum Message](#) <> [Reply to Message](#)

The problem I have is the platter wont turn. I can feel the motor vibrating but not turning. I measured the voltage on motor pcb,I'm getting -13.75 and +9.45(the stated voltage is +/-12) Any help?Thanks
