
Subject: Speed too fast

Posted by [mike d](#) on Tue, 22 Nov 2005 01:50:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

i just bought an old pioneer pl 516. I didnt have a belt so i bought a replacment. Table seems to be in good condition. Anyway....i throw a 33 on there and it sounds like alvin and the chipmunks. Ive never owned a turntable so i dont know if im doing something wrong. i have it set at 33rpms. i have the pitch set as slow as possible but the record still plays fast. What can i do here? is this fixable?
