

---

Subject: Re: Turntable hum

Posted by [Manualblock](#) on Wed, 30 Nov 2005 12:42:05 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Then we are left with an overloaded input to the soundcard or a ground loop in the AC line sequence; thats pretty much what it is. Try a two prong adapter in the turntable plug in to the wall.

---