

---

Subject: Re: turntable channel problems

Posted by [Manualblock](#) on Mon, 09 Jan 2006 01:55:49 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Hi Christine; I remmember your original post. I think you have a bad capacitor in the phono stage but I may not be correct. Which Technics amp do you have?

---