Subject: turntable surface noise in right channel
Posted by daniel on Wed, 01 Feb 2006 14:27:36 GMT
View Forum Message <> Reply to Message

hello, I recently bought a technics SL 1200 MK2. When I play records on it, and there is any surface noise, the noise is always much louder in the right channel, often like a constant crackle, while in the right there will only be a few pops. I thought it was the old cartridge, but I got a new one (a shure cartridge) and the problem persists. any ideas as to the problem? thanks, daniel