

---

Subject: turntable surface noise in right channel

Posted by [daniel](#) on Wed, 01 Feb 2006 14:27:36 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

hello, I recently bought a technics SL 1200 MK2. When I play records on it, and there is any surface noise, the noise is always much louder in the right channel, often like a constant crackle, while in the left there will only be a few pops. I thought it was the old cartridge, but I got a new one (a shure cartridge) and the problem persists. any ideas as to the problem? thanks, daniel

---