
Subject: Re: turntable surface noise in right channel
Posted by [Wayne Parham](#) on Thu, 02 Feb 2006 14:33:09 GMT
[View Forum Message](#) <> [Reply to Message](#)

Maybe check the wiring between cartridge and output jacks.
