

---

Subject: Re: Turntable "skipping" - Help!

Posted by [KARL VEE](#) on Fri, 28 Apr 2006 06:09:19 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

First I'm not familiar with your particular turntable. That said, I assume you have set tracking and anti-skate properly. If your tonearm is the old S-shaped make sure the headshell is parallel to the vinyl, it may need to be rotated slightly. Also could it be a static charge? When I lived in Maryland I had a similar problem in the winter due to dryer air in the house from the HVAC running more often.

---