Found the problem. One of the wires going from the tone arm into the base had somehow been cut in half. It was sticking out from under the tone arm, I dont know how I had missed it before. Thanks.