
Subject: Re: Noise during playback

Posted by [Manualblock](#) on Wed, 31 May 2006 01:03:38 GMT

[View Forum Message](#) <> [Reply to Message](#)

Room temp water and a drop of dishwashing soap will drain a lot of the grime out of the grooves.
Then air-dry and use the cleaning solution.
