

---

Subject: Re: Yamaha YP-B4 sound coming is very low  
Posted by [Wayne Parham](#) on Wed, 21 Jun 2006 17:33:11 GMT  
[View Forum Message](#) <> [Reply to Message](#)

---

You probably need a phono stage for the turntable, and moving coil cartridges are different than moving magnet types, so you need a phono stage appropriate for your cartridge. Most have settings and can work with either.

---