

---

Subject: Re: very low volume comes from the turntable

Posted by [Tre'](#) on Sat, 29 Jul 2006 02:34:29 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

What brand and model is the turntable that is not working? What are you using for a phono preamplifier? Does the mixer have a phono pre in it? Some turntables have a phono pre built into them. Maybe the one that works does and the others don't. That would be an answer if you are plugging into a line level input in the mixer. Tre'

---