

---

Subject: Re: repalcing belt on sony ps-lx250h

Posted by [Wayne Parham](#) on Mon, 14 Aug 2006 21:13:48 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Does the platter have a rubber mat? If so, remove it and check underneath for a couple of access holes. If there are holes in the platter and you can see the base through it, you can access the belt and put it in place. Just rotate the platter and thread the belt into position.

---