Subject: Re: turntable buzz (grounding)
Posted by Bill Rue on Sat, 16 Sep 2006 21:29:18 GMT
View Forum Message <> Reply to Message

Hey Russell:Thanks so much for taking the time to read of my tale of turntable woe. I've used Grado cartridges for many years and have never had this kind of buzzing before. It's only noticeable when the headphone monitor is cranked to '11'. Is the Luxman PD 272 (c. 1982) an unshielded turntable? Thanks for responding!Billinfo@vinylhaven.com