

---

Subject: Re: Sony Turntable Loud Hum

Posted by [Shane M.](#) on Sun, 08 Oct 2006 22:06:50 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Thanks for the reply. Hum is from both channels however, the hum stops when i remove the holder/cartridge from the end of the arm. So i swapped out the cartridge with an older one and the hum is back, so i ruled out a bad cart unless both are bad. I am going to try to replace both RCA cables to see if thats it. There is no grd wire, is this normal? Thanks again.

---