

---

Subject: Re: turntable adjustment

Posted by [Wayne Parham](#) on Tue, 17 Oct 2006 14:45:37 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

The screws you are talking about that tighten the platter down are only used for shipping. When loose, the suspension works and decouples the platter from the feet. That's the way it is supposed to be during use. As for tracking adjustment and cartridge setup, see the link below: [Turntable tone arm and cartridge setup](#)

---