| Subject: Re: Urgent H | elp - Connecting S | Sony Turntable to | Sony System |
|-----------------------|--------------------|-------------------|-------------|
| Posted by DrN on Mo   | n, 08 Jan 2007 20: | :54:46 GMT        |             |

View Forum Message <> Reply to Message

You answered your own question. You need a Phono Preamp since that receiver has no phono input.