
Subject: Re: My turntable is not loud enough
Posted by [Wayne Parham](#) on Mon, 08 Jan 2007 21:13:47 GMT
[View Forum Message](#) <> [Reply to Message](#)

If your receiver doesn't have a phono input, you'll need to connect the turntable to a phono preamp.
