

---

Subject: Tonearm Balancing Problems

Posted by [jason](#) on Wed, 04 Apr 2007 22:22:32 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

First off, I'll readily admit that I'm a newbie to turntables, but I'm eager to learn and get into the thick of things. I recently bought an Audio-Technica AT-PL120 turntable via Amazon. I've been trying to set it up, and when calibrating and balancing the tonearm, I've noticed that the tonearm will not remain steady over to the platter, but consistently swings outwardly back to the tonearm lock. It does this even with anti-skate set to 0. I have checked the leveling of the turntable, but that does not appear to be the issue. Does anyone know what might be the issue here?

---