

---

Subject: Re: Denon DP-300F

Posted by [Bill Epstein](#) on Thu, 26 Apr 2007 07:00:57 GMT

[View Forum Message](#) <> [Reply to Message](#)

---

Have you looked at the stylus under magnification? Could be caked with gunk that can't be brushed off? Try brushing with denatured alcohol. Be careful not to get any on the cantilever where it meets the body, especially if it's a Grado. And/or work at it with a Magic Eraser.

---