Subject: Re: Denon DP-300F
Posted by Michael M on Thu, 26 Apr 2007 23:57:30 GMT
View Forum Message <> Reply to Message

It seems unlikely that it's specifically the stylus, just because I've actually tried another stylus and the problem continued. is it possible the wiring/other connections between the stylus and tonearm are damaged?