
Subject: Re: Technics SL1500 problem - down a channel or ?
Posted by [Wayne Parham](#) on Tue, 04 Sep 2007 13:48:26 GMT
[View Forum Message](#) <> [Reply to Message](#)

Well, one thing is for sure. If the center pin of the right channel's RCA connector isn't conductive, then you'll have no right channel output. Could be that the turntable was used for mono, I suppose.
